

THE CYCLONE

DYCL51AST

7/8" • 22mm




1-1/2"
38mm

This lock is preset to open at L-O-C-K.

To reset the combination:


1. Adjust the dials so L-O-C-K is aligned with the indicators.
2. Withdraw the shackle to open the lock.
3. Place a coin in the center slot on the bottom of the lock and turn the slot in the direction of the arrow so the circle at the end of the slot aligns with the circle next to the arrow.
4. Adjust the dials so your new combination aligns with the indicators.
5. Turn the center slot back to its original position.
6. Close the shackle.
7. To reset the combination again, repeat steps 2-6.
8. Remember to store your combination at masterlockvault.com



Ce cadenas est préréglé pour s'ouvrir à L-O-C-K.

Pour réinitialiser la combinaison :

1. Ajustez les cadrans pour que L-O-C-K s'aligne avec les indicateurs.
2. Retirez l'arceau pour ouvrir le cadenas.
3. Placez une pièce de monnaie dans la fente centrale au bas du cadenas et tournez la fente dans la direction de la flèche pour que le cercle à l'extrémité de la fente s'aligne avec le cercle près de la flèche.
4. Ajustez les cadrans pour que votre nouvelle combinaison de mot s'aligne avec les indicateurs.
5. Remettez la fente central à sa position originale.
6. Fermez l'arceau.
7. Pour réinitialiser de nouveau votre combinaison, répétez les étapes 2 à 6.
8. N'oubliez pas de metre votre combinaison en mémoire à masterlockvault.com.



Limited Lifetime Warranty
Garantie à vie limitée

dudley